



BRISBANE AIRPORT PARKING SIGNAGE PLAN - 2017





The Brisbane Airport Parking Signage Plan (this document) details the landside vehicle TAXI RANK AIRPORT BOUNDARY parking restrictions applicable to the entire Brisbane Airport precinct, in accordance with Taxi ranks only PEDESTRIAN CROSSING commonwealth consolidated regulations of the Airport Regulations 1997. TAXI HOLDING AREA The Restriction outlined herein are applicable to all public and private vehicles, No Stopping, Tow Away zones including motorcycles. Please review the signed parking restrictions for designated PARKING 5MINS MAX locations as detailed below and outlined in key for each individual map drawing. PARKING 2HOURS MAX NO STOPPING AREA PARKING 4HOURS MAX All roads within Brisbane Airport Precincts are NO STOPPING areas except where signed. For security reasons ALL roads are subject to PARKING DISABLED TOW AWAY provisions where vehicles are left unattended. PARKING AUTHORISED BAC TRANSPORT VEHICLES ONLY These areas are marked in red. PARKING APPROVED GROUND TRANSPORT OPERATORS ONLY PICK UP / DROP OFF AREA PARKING TERMINAL PUBLIC For security reasons, drivers must remain with vehicle at all times, Any vehicle left unattended will be subject to TOW AWAY. PARKING MULTI LEVEL CAR PARK Please note: Departure level is for drop off only and Arrival level is for pick up only. PARKING STAFF CAR PARK DISABLED PICK UP /DROP OFF TERMINAL AREA PARKING LONGTERM CAR PARK For security reasons, drivers must remain with vehicle at all times, PARKING QANTAS VALET Any vehicle left unattended will be subject to TOW AWAY. PARKING VIRGIN AUSTRALIA VALET Park 2mins Max Please note: Departure level is for drop off only and Arrival level is for pick up only. PARKING WAITING AREA BUS STOP - BAC BUS Airport approved buses such as the T-Bus, AIRPARK Bus and Staff Bus. BUS STOP - PERMIT BUS (PUBLIC BUS) Public buses operate from Airport to various areas in Brisbane. BUS ZONE Bus Stop Bays, Please refer to posted signs LOADING ZONE Courier and delivery vehicles have designated stopping areas, refer to posted signs LOADING ZONE 20MINS MAX Courier and delivery vehicles have designated stopping areas 20Mins Max, refer to posted signs LOADING ZONE 30MINS MAX Courier and delivery vehicles have designated stopping areas 30Mins Max, refer to posted signs **BRISBANE AIRPORT** PARKING SIGNAGE PLAN Authorised Rep. & Signature Date KEY DEFINITIONS 19/06/17 AIRPORT APPROVALS MANAGER Date 19/06/1 BAC_S_pdf.pltcfg

